Aleratec®

www.aleratec.com

The Prosumers' Choice

QUICK START GUIDE

Aleratec
1:1 HDD Cruiser™

Part No. 350103

Welcome!

Congratulations on your purchase of an Aleratec 1:1 HDD Cruiser, considered by industry experts to be one of the finest Hard Disk Drive Duplicators available.

The entire Aleratec team is committed to providing you with courteous service. Our knowledgeable staff will strive to make owning and operating your new Aleratec 1:1 HDD Cruiser a pleasant experience.

For more detailed information on configuring the 1:1 HDD Cruiser and applying it's various capabilities, please refer to the User Guide on the CD included.

This Quick Start Guide will lead you step-by step through the basic operation procedures of your 1:1 HDD Cruiser.

We at Aleratec appreciate your selection of our product, and wish you great success and enjoyment of your new 1:1 HDD Cruiser.

Check out Aleratec online!

www.aleratec.com
www.twitter.com/Aleratec
www.youtube.com/user/Aleratec

Included Items

- *1:1 HDD Cruiser*
- *Two Hard Disk Drive Bay Keys*
- *USB 2.0 Cable*
- *Power Cord*
- *User Guide CD*
- *Quick Start Guide (this document)*
- *Aleratec Registration Card*

NOTE: Please store and track the included software, registration codes and parts carefully. Requests for replacement software, registration codes, and/or parts may incur a fee.

Product Features

Thank you for purchasing the 1:1 HDD Cruiser. Please read this User Guide thoroughly before using this product. The 1:1 HDD Cruiser is a Hard Disk Drive Duplicator.

- *Duplicates/Makes HDD copies*
- *Sanitizes HDDs*
- *Quick load drive bays*
- *Supports 3.5" SATA HDDs*

Note: Optional 2.5" SATA HDD Adapter 2 pack available (Aleratec Part Number 350106)

Key Items on the 1:1 HDD Cruiser

Note: Choose a Good Location

1. Allow adequate clearance for moving parts.
2. Do not place near heat sources such as radiators or air ducts, or in a place subject to direct sunlight, excessive dust, mechanical vibration or shock.
3. Good care will help assure maximum product life. Improper operating environment and misuse may void the warranty.

Introduction

1:1 HDD Cruiser Front Panel

1 Drive Bays

Drive bays with quick loading doors.

2 Drive Bay Door

The drive bay handle/tab is used to open the individual drive bays.

3 Drive LEDs

Each HDD bay has a blue power light that will be on when there is an HDD properly inserted in the drive bay.

Each HDD bay has an orange drive activity light that will light when the HDD is being used. Do not remove a drive when this light is on, otherwise you may loose your data.

Introduction

1:1 HDD Cruiser Copy Controller Display Panel and Buttons

(Actual display may vary from illustration)



1. LCD display shows all functions and messages
2. **ENT** button is used to execute a selected function, or enter a menu
3. **ESC** button is used to cancel a selected function, or exit a menu
4. **UP** arrow is used to scroll backward through functions or menus
5. **DOWN** arrow is used to scroll forward through functions or menus

Precautions

Before installing you 1:1 HDD Cruiser, please read the following.

Installation

Avoid placing the 1:1 HDD Cruiser in a location subject to:

- High humidity
- High temperature
- Excessive dust
- Mechanical vibration
- Direct sunlight
- Electromagnetic radiation

Transportation

Keep the original packing materials for future moving or shipping of the 1:1 HDD Cruiser.

Overview

Power Up Sequence

During the normal power-up sequence of the 1:1 HDD Cruiser, the following information will be displayed.

- Figure 1 shows the firmware version

- Figure 2 shows the memory initialization

- Figure 3 shows the scanning of the drives

- Figure 4 shows the number of drives loaded.

- Figure 5 shows the first function.

Overview

Main Menu

There are ten main menu items that can be seen in the 1:1 HDD Cruiser Copy Controller Display Panel. These are:

1.

2.

3.

4.

5.

6.

7.

8.

9.

10.

Note: The Advanced Setup function is a hidden menu. To access this menu, press **ESC** for 3 seconds. After you have completed any desired adjustments, press **ESC** to exit Advanced Setup.

Overview

Subfunctions

The “Setup” menu has nine (9) subfunctions. These are:



Overview

The “Advanced Setup” menu has ten (10) subfunctions. These are:



Using the 1:1 HDD Cruiser

Loading the Hard Drives

1. Open the drive tray doors by lifting the tab on the left side of each drive bay you wish to use.

2. Take the Hard Disc Drive (HDD) and align the drive's SATA plug to the lower right hand side of the drive bay.

3. Slide the HDD into the drive bay until it stops. The drive will still be about 1 inch outside of the bay. When the door is closed it will push and plug the HDD into the duplicator.

4. Swing the drive bay door closed and press the left side of the door until the tab latches. When it latches, a click can be felt and heard.

Note: If you are duplicating, the source hard disc drive goes in the top bay.

Using the 1:1 HDD Cruiser

Removing hard Drives

1. Open the drive tray doors by pulling the handle/tab on the left side of each drive tray door.

   Note: Do not attempt to remove the hard drive if the drive activity LED is on.

2. To disengage the HDD, swing the drive tray door to the full open position.

3. Pull drive out toward you, and remove drive.

Technical Support Addresses and Phone Numbers

- *By e-mail:* ***support@aleratec.com***
- *By Telephone:* ***1-818-678-0484***

  Technical Support Group can be reached 8:00 AM to 5:00 PM, Pacific Time, Monday through Friday, excluding U.S. holidays.

  Please try to call from a phone near your computer system.

- *Access is available 24 hours a day, 365 days a year, via:*

  The World Wide Web at: ***www.aleratec.com***

  FAX at: ***1-818-678-0483***

Notes:

Notes:

Document Number: 9299060_ENG_Rev. J
Specifications subject to change without notice.

Copyright © 2010

Aleratec, Inc.
9851 Owensmouth Avenue
Chatsworth, CA 91311 U.S.A.

www.aleratec.com